

Standard delivery

Installation accessory

Special installation

Accessory



Supplies and accessories

		26CC / 40 CC
4031	Fuel tank socket case	○
4206	Timer/week program, mechanical	○
363055	Timer cable	○
4430	Remote control system	*
4004	Exhaust head	●
4880	Mounting kit	●
30017	Solenoid valve	○
4130	Fuel tank, 130 l	○
4030	Fuel tank, 30 l	●
2027	Fuel tank, 10 l	●
4045	Combustion air pipe Ø 45 mm, Al	●
4845	Exhaust pipe Ø 50/45 mm, stainless	○
4033	Protection tube 0,5 m, fuel hose	○
363054	Control panel cable, 6 m	○
4032	Extension line, 2 m	○
4012	Insulating channel	○
4015	Insulation mantel plate Ø 115 mm / 0,3 m	○


Alternative front panels and their content

26GF	
1 pcs	Front panel, grey 26CC
4 pcs	Fastening screw M4x16
26PF	
1 pcs	Front panel, pine pattern 26CC
4 pcs	Fastening screw M4x16
40GF	
1 pcs	Front panel, grey 40CC
4 pcs	Fastening screw M4x16
40PF	
1 pcs	Front panel, pine pattern 40CC
4 pcs	Fastening screw M4x16



Front panel, grey

Installation:
See page 55.



Front panel, pine pattern

Device package contents

26CC / 40CC	
1 pcs	Heater without front panel
1 pcs	Control panel package 361061A
1 pcs	Control panel
1 pcs	Control panel rim for surface mounting
1 pcs	Control panel cable, 3 m
4 pcs	Control panel fastening screws 3,5x40
1 pcs	Power cable with connector and integrated fuse 15 A (4m)
1 pcs	Fuel hose, 4 m
1 pcs	Fuel tank connection
1 pcs	Short circuit connector for mountain switch
1 pcs	Accessory bag 260941A
1 pcs	⑩ Hose binder 32-50 mm
1 pcs	⑪ Pipe clamp 48 mm
4 pcs	⑫ Fastening screws 5x30 (black)
1 pcs	Installation, operation and maintenance instructions